



TECHNICAL DATA SHEET

CA906

Description ULTRABOND CA906 is a low viscosity ultrafast setting velocity ethyl cyanoacrylate adhesive. It is specially for difficult to bond substrates.

Application Ideal for bonding plastics, rubber, TPR elastomers. Special for difficult to bond rubber compounds. Including EPDM, nitrile, neoprene, viton, EVA, SBS, rubber, ABS, plasticized PVC & rigid PVC. For polyolefin (PE, PP) bonding, use ULTRABOND CP-1 Primer. Equivalent to Loctite's 406

Full Cure Speed

Plastic	:	2 - 30 seconds
Rubber	:	2 - 30 seconds
Metal	:	2 - 30 seconds
Wood	:	2 - 30 seconds

(22°C, 50% relative humidity ASTM D1002, 0.1 N/mm² tensile shear strength)

General Properties

Uncured monomer

Main Component	Ethyl Chanoacrylate
Appearance	Clear Liquid
Specific gravity, 25°C	1.05
Viscosity 25°C (CPS)	18-26 CPS
Brookfield LV	
Spindle S31@ 100rpm	>80°C
Flash point	
Shelf life (8°C) months	6

(Stored in cool & dry place, unopened bottle & out of direct sunlight)

Cured Adhesive

Gap Filling	0.05 mm
Tensile Strength	10-20 N/mm ²
Steel - Steel ASTM D-2095	
Tensile shear Strength	10-20 N/mm ²
Steel/ Steel ASTM D-1002	
Service Temperature Range	-55 to 82°C
Full cure time	24 hours

Safety Direction

Danger, irritant

** All the information is provided on the basic in good faith, and is believed to be trustworthy but is for reference only. Adhesion is very complicated and the result of it is much dependent on the surface material, additives, releasing agents of the substrates and user's methods. UEA and its agents, dealers, distributors, directors and employees cannot accept any liability for the results whatsoever arising from the use of UEA's products due that the utilization of these products is simply out of UEA's control. The users are responsible for selecting the suitability of the products and methods of use



TECHNICAL DATA SHEET

Avoid contact with eyes and skin, bonds skin in seconds. In case of eye contact, flush with plenty water for over 15 minutes; call a physician immediately. Use in well-ventilated place. Avoid contact clothing; it can cause very strong heat.

Application Direction

- ◆ The surfaces to be bonded should be clean and free of grease completely.
- ◆ ULTRABOND CD-1 Debonder or acetone can treat excess Adhesive.
- ◆ If setting time is too long due to large gaps or low relative humidity. ULTRABOND CS-1 Setter can be used.
- ◆ If the porosity of surface is higher, higher viscosity type should be better.
- ◆ Difficult to bond plastics, like PE, PP, Silicone Rubber, ABS, TPR, EPDM's Adhesion, ULTRABOND CP-1 Primer should be applied firstly, then applied ULTRABOND super glue.